

AUSTELL STACKING OPERATION

Operational change for international units

March 13, 2024

Brad Carper Director - South, Intermodal and

Automotive Terminal Operations

Randy Durden

Zach Hollis

Hub Manager Southeast, Intermodal and Automotive Terminal Operations ations Manager South

Operations Manager Southeast, Intermodal and Automotive Operations



Driver Action/Experience

01 Recap
02 Driver Route
03 Driver Rules
04 Resources




International Stacking Operation

- All International units will be stacked
- Terminal Chassis status
 - Pickup and Drop
- Chassis Availability
 - Contact Pool provider
 - Chassis can't be left on terminal
- Technology required by driver
 - ExpressNS+ or accept texts
- Staging area

Recap: Appointment System powered by Blume

- 1 hour appointment window*
- Must have container number and billing or pickup number to activate appointment
- May make a pending appointment, complete later
 - Pending will be cancelled if incomplete
 - (30 min prior to scheduled appointment)


02 DRIVER ROUTE





QUE TRK – STAGING AREA

NS Austell IMF – Terminal Parking Map






w

QUE TRK – STAGING AREA





UNLOCK PINS – SAFETY AREA






UNLOCK PINS – SAFETY AREA





STACK ENTRANCE






STACK ENTRANCE






TRANSFER SPOT and BYPASS LANE






TRANSFER SPOT and BYPASS LANE








LOCK PINS – SAFETY AREA






NS Austell IMF – Terminal Parking Map

6000 Dr. Luke Glenn Garrett, Jr. Memorial Highway, Austell, GA 30106



03 DRIVER RULES






Driver Rules

- Pins MUST be unlocked prior to entering stack module
- Lock all door handles and latches
- Enter from North end
- Drive in BYPASS LANE to access transfer slot
- Obey traffic lights, located on each crane
- Driver MUST park fully in Transfer slot
 - Do not straddle line nor block number
 - No reversing
- Driver MUST be out of truck for lift
 - Stand on Slot number with PPE
 - No roaming

ALWAYS USE CAUTION





RTG TRAFFIC LIGHTS



04 RESOURCES





Applicable Driver Screens ExpressNS+ vs NON user


BACK Transfer Spot Location

TCLU805103 AUSTELL

Transfer Spot S01 125 BACK

Please drive to transfer spot and wait.

Parking Zone S01 125



OUE TRK

0712497869 ORFOLK BOUTHER NS Intermodal Austell Yard Pass Mar 11 2024 12:42PM TEST DRIVER BJ WARGO TRUCKING (DIV MGR) Equipment Delivery (In) CMAU673404 Equipment Chassis APMZ410458 Park at: LOT S01, ROW 101 Instructions: Please proceed into the terminal and park the equipment listed above in the specified location. Damage is captured on Recorded Images Please maintain AT LEAST 30FT following distance between trucks when driving through the inspection portals. Failure to do so will result in suspension from the terminal. Do not stop in the inspection portal.

Message Text

Norfolk Southern Intermodal Customer: Pin Number 922860. Please enter your pin number 922860 into the kiosk screen to complete your ingate transaction. Message freq varies. Msg and Data rates may apply. Reply Stop to cancel. Reply Help for Info.

Norfolk Southern Intermodal Customer: Thanks for joining! Message freq varies. Msg and Data rates may apply. Reply Stop to cancel. Reply Help for Info.

Norfolk Southern Intermodal Customer: Please proceed to staging area QUE TRK. Further instruction will be provided directing you to a transfer spot position. Message freq varies. Msg and Data rates may apply. Reply Stop to cancel. Reply Help for Info.

Norfolk Southern Intermodal Customer: Please proceed to transfer spot 112. Message freq varies. Msg and Data rates may apply. Reply Stop to cancel. Reply Help for Info.

Norfolk Southern Intermodal Customer: Please confirm arrival to transfer spot 112. If you are in the assigned location please respond with Y. Message freq varies. Msg and Data rates may apply. Reply Stop to cancel. Reply Help for Info.

Resources available

• Blume website

https://apps.blumesolutions.com/signup/



ExpressNS+



- NS | Norfolk Southern
 - Ship by Rail
 - Shipping By Industry
 - Intermodal / Overview
 - Select "Terminals and Schedules"
 - Select Download Stack Optimizer Details



CCM POOL CHASSIS YARD

Address Type:	Operations Location	Country:	USA
Street Address 1:	11030 Veterans Memorial Hwy		
Street Address 2:			
City:	Lithia Springs	State / Province:	Georgia
Postal Code:	30122	Office Phone:	(678) 246-9915
Fax Phone:			




FLEXI CHASSIS YARD

Address				
Address Type:	FLEXI Location	Country:	USA	
Location	CMC Austell/Powder Springs Depot			
Street Address 1	4985 Huddleston Drive			
City:	Powder Springs	State / Province :	Georgia	
Postal Code:	30127	Office Phone:		
Fax Phone:				



YOUR TURN:

Q&A







Thank You www.norfolksouthern.com